



1912 DASH

Speedometer hole pattern is typical for Stewart Model 26 and others. The Speedometer is mounted 3/16" to the left of the floor board notch for the speedometer cable. The Speedometer cable thus slants to the right side as it passes through the floorboard and on through the hole in the splash apron on the outside of the frame rail. Speedometer is mounted with #9 x 5/8" Slotted Round Head Brass Wood Screws

Title Speedometer Mounting (Typical 1912)			
Drawn By JFR	Dir\Filename Speedomnt.dwg	Issue Rev A1	Total Pages 1
Origin Date 7/04/03	Part Number F/N 5257	Revision Date 7/04/03	Page Number 1

Fun Projects, Inc.

PROPRIETARY- Information presented in this document is the property of Fun Projects Incorporated and may not be sold or distributed without specific written permission.