

DIAGRAM No. 5
IGNITION WIRING




Fig. 16.—View of Ford Power Plant Showing Main Parts of the Ford Ignition System. Note Location of Timer and Induction Coil Box.

LIGHTING CIRCUITS ON FORD CAR

Two lamps can be connected in series to operate from the magneto, as shown in Fig. 100 below.




Fig. 100. The wiring above shows the ignition and also two lamps in series which take current from the magneto on Fords that are not equipped with a starting and lighting system. The horn switch or button is on the steering post.