

Area	Part Number	Replacement Number or Explanation	Name	Size	Length	Thread	Head	Torque	Features	# per car
T Parts										
Rear Axle	2503E		Rear axle housing Bolt	5/16"	1 5/16"	24	Hex			7
	2503F		Rear axle housing Nut	5/16"		24	Hex		use lock washer	7
	2505		Axle Shaft	5/8"		18			2505HS is 1/16" longer made of High Strength Steel (4140)	2
	2507		Axle shaft nut	5/8"		18	Castle			2
	2514	1909-1915	Differential Case Stud	3/8"	2 3/4"	24				
	2514B	1915-1921	Differential Case Stud	3/8"	2 1/4"	24				
	2514C	1921-1927	Differential Case Bolt	3/8"	3 3/8"	24	Hex		Drilled for wire. Based on year, only one applies	3
	2515	1909-1921	Differential Case Nut	3/8"		24	Castle			3
	2519		Ring gear to differential bolts	5/16"	21/32"		Hex			10
	2519A		Differential lock ring halves	?	?					
	2521B		Differential axle gear key	?	?				prevents axle gear from coming off	4
	2530	?	Thrust plate pin		13/32"					
	2531	?	Thrust plate pin		7/32"					
	2531B	1912-1927	Thrust plate pin	?	?				3 per side of rear end; 1 pin on each side of the center differential carrier	6
	2532	1913-1927	Differential drain plug	3/4"		20	hex		can get a magnetized one using 2532M	
	2532B	1926-1927	Differential drain plug	3/4"		20	square hole drive			
	2532E	1909-1912	Differential drain plug	3/4"		20	slot on top			
Rear Radius Rod	2545		Grease cup	1/8 "			pipe		Can get one with modern grease fitting hidden inside. These can be either brass or steel based on year and desire.	2
	2551		Rear Radius Rod Bolt	1/2"	1 1/2"	20	Hex			4
	2551B		Rear Radius Rod Nut	1/2"		20	Castle		connects radius rod to axle housing	4
	2563		Rear Radius Rod Cotter Pin		7/8"					4
	2548		Nut	9/16"	3/4"	18	Castle			2
	2549	1909-1925?	Nut	9/16"		18	Hex			2
	2550		LW	9/16"						2?
Brakes	2563	1909-1925	Brake Camshaft Lever Pin	3/16"	7/8"?					4

	2563B	1926-1927	Brake Camshaft Lever Pin	3/16"	7/8"?			Use 3045	4
	2564		Brake Rod Clevis pin	5/16"	1"		Button head	maybe 15/16" long	4
	2567		Brake Shoe support bolt	1/2"	1 7/8"	20	Hex	Drilled	2
	2568		Brake Shoe support Nut	1/2"		20	Castle	can use 2551B	2
Torque Tube / Drive Shaft									
	2574		Universal Joint knuckle pin	3/32"	1 1/2"				1
	2576		Universal Joint Ball Rivet	1/4"	1 1/8"		Round		4
	2578	1919-1927	Universal Joint Plug	1/2"	1/2" ?	20	Hex	Flat head style	2
	2578E	1909-1918	Universal Joint Plug	1/2"	1/2" ?	20	Hex	Domed head style	2
	2579		Grease cup	1/4"			pipe		1
	2584	1912-1921	Drive Shaft Roller Bearing Housing Stud	?				Drilled for wire	6
	2584C	1912-1921	Drive Shaft Roller Bearing Housing Nut	7/16"		20?	Castle	used with 2584	6
	2584B	1922 - 1927	Drive Shaft Roller Bearing Housing Bolt	13/32" (7/16"?)	4 5/8"		Hex	Step Bolt	6
	2584D		LW	7/16"				What is this????	6
	2586	1911 - 1921	Drive Shaft Roller Bearing Housing Set screw	1/2"	1/2"	20	Hex		1
	2598		Drive Shaft Nut	5/8"		18	Castle		1
	2598B		Drive Shaft Pinion Key		?				1
Front Axle									
	2691		Axle, front	1/2"		20		Lower spindle bolt hole	2
			Nut					3 different sizes, total quantity 8 2691S	
			Nut						
			Nut						
	2694B	1911 - 1925	Spindle body - Right	3/4"		16 RH			1
	2694C	1926 - 1927	Spindle body - Right	3/4"		16 RH			1
	2695B	1911 - 1925	Spindle body - Left	3/4"		16 LH			1
	2695C	1926 - 1927	Spindle body - Left	3/4"		16 LH			1
	2696C	1919 - 1927	Spindle arm -right	9/16"		18			1
	2696D	1919 - 1927	Spindle arm - left	9/16"		18			1
	2697	1911 - 1927	Spindle Arm Nut	9/16"	3/4"	18	Castle	can use 2548	2
	2705	1909 - 1919	Adjustable Cone RH Thread	3/4"		16 RH		For left ball bearing hub	1

2706	1909 - 1919	Adjustable Cone LH Thread	3/4"		16 LH		For right ball bearing hub	1
2707		Spindle nut with RH thread for drivers side	3/4"		16 RH	Castle		1
2708		Spindle nut with LH thread for passengers side	3/4"		16 LH	Castle		1
2709		Spindle Washer	3/4"				use 2709E for shorter spindles	2
2710A	1909 - 1916	Spindle bolt	1/2"	?	20	Hex		2
2710H	1917 - 1927	Spindle bolt	1/2"	?	20	Hex		2
2711	Use 2568 or 2551B	Spindle bolt Nut	1/2"		20	Castle	Use 2568 or 2551B	2
2715 D	1917 - 1927	Flip top, press in type oiler					can also use 3176 C 4 large oilers for spindle and tie rod bolts	4
3817	1909 - 1916	Brass oiler, threaded twist type	1/8"		1/8 pipe		Brass 4 large oilers for spindle and tie rod bolts	4

Tie and steering rods

2717	1919 - 1927	Threaded tie rod			?		unknown about end piece that screws on.	1
2718E	1909 - 1911	Tie rod bolts with slotted head	7/16"	2 1/4"	20	Hex	Drilled for cotter	2
2718A	1911 - 1916	Tie rod bolts	7/16"	2 1/4"	20	Hex	Drilled for cotter	2
2718B	1917 - 1927	Tie rod bolts	7/16"	2 1/4"	20	Hex	Drilled for cotter	2
2719		Tie Rod Nut	7/16"		20	Castle		2
2721A	1911 - 1918	Tie rod yoke ball	7/16"		20	Ball	straight shaft	1
2721B	1919 - 1927	Tie rod yoke ball	7/16"		20	Ball	tapered shaft	1
2721N	1911 - 1927	Tie rod yoke nut	7/16"		20	Castle	Can use 2719	1
2722		Steering Yolk Bolt set	3/8"	1 1/8"	24	Hex / Castle	This is a set of bolt/nut/cotter pin Use 3362 - ??	1
2722B		Steering Yolk Nut	3/8"		24	Castle	Use 2515	1
2729B		Steering geat rod ball cap bolt & nut	3/8"	1 1/8"	24	hex / castle	drilled for cotter pin - 1 set is 2 bolts/nuts/cotter Use 1- 2722 + 1- 2722B or 1-3362 & 1-2515	1
2728ADJ		Adjusting screw				slotted	Adjusting screw for spring loaded tie rod ball cap - accessory	1

Front Radius Rod

2741		Radius cap mounting stud	3/8"	2 7/8"	16 / 24		Drilled on the 3/8" x 24 end	2
2741B		Radius cap mounting stud Nut	3/8"		24	Castle	Use 2515	2
2734 ?	Use 2548	Nut	3/8"		24	castle	Use 2548	
2741C		Bolt	3/8"		24		What is this?	1

Hubs and Wheels

2803	1912 - 1925	Front hub - wood wheels	2 1/8"		24		also listed as 2803B	2
2803U	1919 - 1927	Front hub - wood wheels	2 1/8"		24			2
2815C	All	Rear Hub - wood wheels	2 1/8"		24			2
2816B		Rear axle hub key	?	?				2
2819	All	Hub cap	2 1/8"		24			4
2825	1911 - 1927	Rear Hub Bolt	3/8"	2 1/8"	16	Round	Round Head w/ Square shoulder	12
2826	1911 - 1927	Front Hub Bolt	3/8"	2"	16	Round	Round Head w/ Square shoulder	12
2825E	1906 - 1910	Front / Rear Hub Bolt	3/8"	2 1/8"	16	Round	Round Head w/ Square shoulder	24
2825EN	1906 - 1910	Front / Rear Hub Nut	3/8"		16	Hex		24
2825BQ	1911 - 1927	Front / Rear Hub Bolt	3/8"	2 1/8"	16	Round	Round Head w/ Square shoulder	24
2825B	1911 - 1927	Hub Bolt Nut	3/8"		16	Hex / Special	Special	24
2828		Nut	5/8"		18	Castle		2
2847	1919 - 1927	Demountable rim bolt	3/8"	?	16	Special ?		16
2848	1919 - 1927	Demountable rim nut	3/8"		16	Hex / Special	Special	16
2834		Front Hub Inner Roller bearing	3/4"		16 RH?		Not threaded?	2
2837		Outer Roller Bearing for Left Front Hub	3/4"		16 RH			1
2838		Outer Roller Bearing for Right Front Hub	3/4"		16 LH			1
2846B	1919 - 1924	Demountable rim removable lug (clamp)	3/8"		16			16
2848 B	1919 - 1924	Demountable rim bolt nut	3/8"		16	Hex / Special	sqare shoulder for Kelsey wheels and rims only.	16
2849B		Bottom Spare Tire Carrier Bolt	?		?			1
2849B2		Bolt	?		?			1
2849B3		Bolt	?		?			1
2872		Spare rim bracket	1/2"		20		bolts	
2872B		Spare rim bracket	1/2"		20		bolts	
2872C		Spare rim bracket	1/2"		20		bolts	
2875	1919 - 1925	Spare tire carrier mounting stud	1/2"		20		can use 2883	1
2875B	1926 - 1927	Spare tire carrier mounting stud	1/2"		20			3
2876		Spare tire carrier mounting stud nut	1/2"		20			3
2877		Pin	?					1
2877B		21" Split rim lock screw						1
2877B2		Screw	?					1

	2883	1926 - 1927	Wire wheel front hub bolt (stud)	1/2"		20			10
	2888	1926 - 1927	Wire wheel rear hub bolt (stud)	1/2"		20			10
	2884	1926 - 1927	Wire wheel nut	1/2"		20	Hex	chrome plated	22
	2890		Nut	1/2"		20	Hex	Special	1
Gasoline									
	2901	1912 - 1924	Gas cap / plug	?				new reproduction, early recessed style	1
	2901B	1924 - 1927	Gas cap / plug	?				wing style, brass plated, no script	1
	2901BQ	1924 - 1927	Gas cap / plug	?				2 piece with air vent splash guard	1
	2901BR	1909 - 1911	Gas cap / plug	?				early recessed style, solid brass	1
	2901Ci	1911 - 1917	Gas cap / plug	?				cast iron	1
	2901T	1911 - 1912	Gas cap / plug	?				winged cap for torpedo roadsters, solid brass	1
	2902	1909 - 1910	Sediment bulb	?				threaded style	1
	2902AB	1911 - 1912	Sediment bulb	?				torpedo and open runabout, brass	1
	2902AS	1911 - 1912	Sediment bulb	?				torpedo and open runabout, steel	1
	2902B	1912 - 1927	Sediment bulb	?				bulb and shutoff, brass, can be painted, not for cowl tanks	1
	2902CBQ	1926 - 1927	Sediment bulb	?				cowl type gas tank	1
	2902NRS	1906 - 1908	Sediment bulb	?				brass	1
	2907	1909 - 1912	Pet cock, fuel line shutoff			1/8" NPT		brass	1
	2908OR	1909 - 1927	Pet cock for sediment bowl			1/8" NPT		brass	1
	6055	1909 - 1927	Gas line shut off valve			1/8" NPT		brass - replaces right angle inlet connections	1
	6055RE	1909 - 1927	Gas line shut off valve			1/8" NPT		brass - replaces right angle inlet connections going into the carburetor	1
	2908B	Use 6216	Drain plug						1
	2910	For gas line	Gas feed Pack nut			1/2" NPT?	Hex / Special	Brass	2
Engine Components									
Head Bolts									
	3003	1909 - 1917	Low cylinder head bolt	7/16"	2 3/4"	14	Domed Hex		15
	3003B	1918 - 1927	High cylinder head bolt	7/16"	3 1/4"	14	Domed Hex		15
	3003C	1926 - 1927	High cylinder head bolt	7/16"	3 1/4"	14	Domed Hex	Nickel plated	15
Water inlet/outlet									
	3008	1914 - 1927	Cylinder upper outlet connection bolts	7/16"	15/16" ?	14	Domed Hex		2
	3008E	1909 - 1913	Cylinder upper outlet connection bolts	7/16"	15/16" ?	14	Domed Hex	Special thick head	2

3057		Valve pin	7/64"	17/32"				holds valve spring seat in place	8
Crankcase									
3072		Bolt	3/8"	1"	24	Hex		Drilled	2
3074C		Bolt	?	?		?		Drilled	1
3073		Crankcase Arm Bolt - Side	3/8"	2 1/4"	24	Hex		Drilled	2
3074		Crankcase Arm Bolt - Top	3/8"	2 1/4"	24	Hex		Drilled	2
3074B		Crankcase Arm - Nut	3/8"		24	Hex		Castle	4
3075	1909 - 1921	Crankcase front spring clip	7/16"		20			7/16" hole drilled for top cap bolts	1
3075B	1922 - 1927	Crankcase front spring clip	7/16"		14			7/16" hole drilled for top cap bolts	1
3076C		Crankcase front bearing and spring clip nut	7/16"			Hex		Castle	2
3078	1909 - 1921	Crankcase Front Bearing Bolt	7/16"	7/8"	20	Hex		Drilled	2
3078B	1922 - 1927	Crankcase Front Bearing Bolt	7/16"	7/8"	14	Hex		Drilled	2
3078C		LW	7/16"						1
3079		Oil cock	1/8"		NPT			brass	2
3080E	1909 - 1912	Oil Plug	?		?	slotted			1
3080	1913 - 1927	Oil Plug	?		?	hex		Use 2532	1
3101B	1912 - 1924	Crankcase lower reinforcement	5/16"					13 holes - for 3 dipper	1 set
3101 C/D	1925 - 1927	Crankcase lower reinforcement	5/16"					17 holes - for 4 dipper	1 set
3103		Crankcase Lower Cover Bolt	5/16"	7/16"	18	Hex		13 for 3 dipper pan	17
Engine Compartment									
3088B	1909 - 1927	Engine Pan and Hood Shelf Bolt - Front	1/4"	3 1/4"	20	Carriage		1" of threads	2
3088C	1909 - 1927	Engine Pan and Hood Shelf Bolt - Rear	1/4"	3 5/8"	20	Carriage		1" of threads	2
3088D		Engine Pan and Hood Shelf Bolt	1/4"	?	20	Carriage		1" of threads old # 1128	2
3088E		Engine Pan and Hood Shelf - Nut	1/4"		20	Hex ?		used with B,C, & D	4
Valve Cover									
3110WN	1911 - 1912	Wing nut for cylinder valve cover	3/8"		16	wing nut			2
3112	1912 - 1920	Cylinder Valve cover Stud	3/8"	2 29/32"	16	Hex			2
?	1912 - 1920	Cylinder Valve cover Nut	3/8"		16	Hex			2
3112B	1921 - 1927	Cylinder Valve cover Bolt	3/8"	2 29/32"	16	Hex			2
3115		Rivet	?	?		?		crankcase rivet?	?
Commutator									
3162	1912 - 1919	Commutator case support bolt	3/8"	2 1/4"	24	Hex			1

	3162B	1919 - 1927	Commutator case support bolt	3/8"	4 9/16"	24	Hex	Head 3/16" thick - for cars with generators	1
	3162DT	1919 - 1927	Commutator case support bolt	3/8"	4 9/16"?	24	Hex	Head 3/16" thick - for cars with generators - Distributor	1
	3176	1912 - 1916	Oiler					brass - threads in	1
	3207	1909 - 1927	Timer Brush Cap Pin	1/8"	13/32"				1
	3220		Commuter Lock Nut	9/16"		18	Hex		1
	3210		Nut	#10			Hex	brass or copper?	8
Magneto / Flywheel	3252	1909 - 1927	Magneto Coil Support Bolt	3/8"	13/16"	16	Hex	Drilled for safety wire. Can use 3371	4
	3254		Magnet Bolt	3/8"	1 1/2"	16	Hex	Drilled?	16
	3255B		Magnet Bolt Washer	7/8"				25/64" hole	16
	3260	1917 - 1925	Magnetic Field Coil Contact Assy	1"?			Hex		1
	3260A	1909 - 1917	Magnetic Field Coil Contact Assy	1"?			Hex		1
	3260B	1926 - 1927	Magnetic Field Coil Contact Assy	1"?			Hex		1
	3260 E1	1909 - 1912	Magnetic Field Coil Contact Assy	1"?			Hex		1
	3260 E2	1913 - 1914	Magnetic Field Coil Contact Assy	1"?			Hex		1
	3260 E3	1915 - 1917	Magnetic Field Coil Contact Assy	1"?			Hex		1
	3261B		Nut	?			?	?	2
	3261C		Washer	?				?	2
	3266		Fibre Screw	?	1/2"		?	holds contact assembly in?	3
	3270		Flywheel to Crankshaft Bolt	7/16"	1 3/16"	14?	Hex	Drilled head	4
	3271		Flywheel Dowel Pin	15/32"	1 3/16"			Align crankshaft / flywheel	2
	3278	1911 - 1927	Magnet Clamp Screw	#14?	2 25/32"	24	slot	14 x 24 or 1/4" x 24 - brass	16
Transmission	3301RIV		Transmission Reverse Drum Rivet	7/32"	7/8"		flat 60 deg	Stainless Steel	8
	3305		Transmission Brake Drum Rivet	7/32"	3/4"		flat 60 deg	Stainless Steel may be 3311RIV	8
	3305L		Transmission Brake Drum Rivet	7/32"	7/8"		flat 60 deg	Stainless Steel	8
	3306RIV		Transmission Slow Speed Drum Rivet	7/32"	7/8"		flat 60 deg	Stainless Steel	8
	3325RIV		Transmission Driving Plate Rivet	1/8"	5/8"		flat 60 deg		8
	3315		Triple Gear Pin / Rivet	3/16"	1 3/16"				3
	3318		Transmission Driven Gear Key						2
	3323	1909 - 1925	Transmission Driving Plate Screw	3/8"	13/16"	16	Hex	Can Use 3371	6

3323B	1926 - 1927	Transmission Driving Plate Screw	3/8"	?	16	Hex		6
3333		Transmission Clutch Disk Drum Key						1
3334		Transmission Clutch Disk Drum Set screw	3/8"	3/4"		hex	may be square or hex	1
3337 1/2	1909 - 1925	Transmission Clutch Finger Screw	3/8"	3/4"	24	slot-no head		3
3337B		Transmission Clutch Finger and Screw	3/8"	?	24	?		3
3338		Clutch Finger Pin with head	11/32"	1 5/8"				3
3342		Transmission clutch spring support pin	5/16"	2 3/8"				1
3362		Bolt and nut	3/8"	1 1/8"	24		Use 1-2722 & 1-2722 B	
3362B		Nut	3/8"		24	?	Use 2515	6
3367		Transmission cover door screw / bolt	5/16"	1/2"	18	round head, slotted	Many people replace this with a hex headed bolt.	6
3371		Bolt	3/8"	13/16"	16	Hex	What is this?	2+
3372		Bolt & nut					Use 1-2722 & 1-2722 B or 3362 & 2515	
3375		Screw / bolt					Use 3072	
3384	1926 - 1927	Transmission cover to block cap screw	7/16"	1 1/2"	14	Hex	Can use 3016	2
3403		Clutch Lever Screw	3/8"	1 5/16"	24	Hex	Used for clutch adjustment	1
3403B		Nut	3/8"		24	Hex		1
3405		Clutch Lever Pin	1/4"	1 3/16"			Attaches clutch lever to clutch shaft	1
3406C	1913 - 1927	Clutch release fork pin	1/4"	1 3/16"			Can use 3405	2
3408		Key		?				2
3409	1909 - 1914	Clutch release fork screw	3/8"	13/16"		?		2
3411		Clutch Lever Clevis Pin	5/16"	1"		Button head	attach slow speed connector to clutch lever Use 2564	1
3419	1909 - 1925	Low Band Adjusting Screw	3/4"	3 1/8"	16			1
3419B	1926 - 1927	Low Band Adjusting Screw	3/4"	?	16		For bands with detachable ears	1
3420		Low Band Adjusting Screw Lock Nut	3/4"		16	Hex		1
3421		External Band Adjuster Set					set of two with nuts/shafts/etc - for reverse and brake	2
3421B		Rivet	3/16"	3/8"		?	Iron	12

	3421C		Rivet	?	?	?	Iron	6
	3422B		Band Rivet	9/64"	1/2"	?	Brass - package of 25. Enough for all three bands.	6
	3426		Band Adjusting Nut	7/16"		20 notched hex	notch fits band adjusting nut washer	2
Pedals	3429		Slow speed notch pin	1/4"	1 5/16"			1
	3437	1909 - 1925	Pedal Support Bolt	3/8"	?	24		2
	3437B	1909 - 1927	Pedal Support Nut	3/8"		24	Castle	2
	3437C	1926 - 1927	Pedal Support Bolt	3/8"	?	24	Can Use 2515	2
	3441		Pedal Pin				Use 3405	3
	3443		Clutch Pedal Support Bolt	3/8"	1 1/2"	24	Hex	1
	3443B		Clutch Pedal Support Bolt Nut	3/8"		24	Hex	1
	3445		Slow speed Connection	5/16"	?	24	L bend	1
	3446		Nut	5/16"		24	Hex	1
	3447B		Slow speed Connection Clevis Pin	5/16"		24		1
	3447E		Slow speed Connection Clevis	5/16"	?	24		1
Hand Brake	3448RIV		Brake Quadrant Rivet Set					4
	3452		Bolt	5/16"	1"	24	Hex	4
	3452B		Nut	5/16"		24	Castle	4
	3456B		Hand Brake Lever Pin		1 1/2"		Use 2574	1
	3457		Key		?			1
	3459		Hand Brake Lever Pawl Pin	7/16"	15/16" ..		flat	1
	3461		Hand Brake Release Handle Rivets		1 3/16"			2
	3466		Hub Brake Lever Pin		1 3/16"		Use 3405	2
	3467	1920 - 1927	Hub Brake Lever Clevis	5/16"		24	Use 3447	2
	3467E	1909 - 1920	Hub Brake Lever Clevis	5/16"		24	Use 3447	2
	3472		Brake Rod Support Bracket Bolt	1/4"	1 1/8"	20	Carriage	2
	3472B		Brake Rod Support Bracket Nut	1/4"	1/2"?	20	Hex	2
Steering	3502	1918 - 1927	Screw - Steering wheel rim to spider	#10	3/4"		Oval head	4

3502BR	1909 - 1912	Screw - Steering wheel rim to spider	#10	3/4"		Oval head	Brass wood screw	4
3502	1913 - 1917	Screw - Steering wheel rim to spider	#10	3/4"		Oval head	Stainless steel wood screw	4
		Screw to hold steering gear cover	#6	9/32"	32	Round	slotted head - keeps steering gear cover from rotating after being screwed on.	1
3507R	1909 - 1914	Steering gear case brass rivet					Brass	6
3509RBR	1909 - 1915	Steering Quadrant to column rivet	.166"	2"			Brass - length cut to size as needed Macs catalog (3510B) lists these as 5/32" diameter	2
3509RBO	1909 - 1915	Steering Quadrant to column rivet	.183"	1 1/2"			Brass - length cut to size as needed - oversize	2
3509RST	1915 - 1927	Steering Quadrant to column rivet	.155"	1 3/8"			Steel - Macs catalog (RV25) lists these as 5/32" diameter by 1 5/16"	2
3511	1913 - 1927	Steering Wheel Nut	15/16"		?	Hex	Steel High crowned	1
3511LC	1906 - 1914	Steering Wheel Nut	15/16"		?	Hex	Brass Low crowned	1
3511B	1915 - 1927	Steering Wheel Nut	15/16"		?	Hex	Brass High crowned	1
3511	1916 - 1927	Steering Wheel Nut	15/16"		?	Hex	Chrome High crowned - accessory	1
3513B	1909 - 1910	Bolt for mounting steering column to the firewall	5/16"	1 1/4"	18	Oval head /counter sunk	3513MB is the bolt/nut set - possibly 1 5/16" long - brass	4
3513BB	1911 - 1912	Bolt for mounting steering column to the firewall	5/16"	1 1/2"	18	Oval head counter sunk	Can Use 4805B - possibly 1 9/16" long - brass. The 1911 - 1912 year actually used 3 of the 3513B bolts and 1 of these longer bolts	4 (3 - 1)
3513BC	1913 - 1923	Bolt for mounting steering column to the firewall	5/16"	1 1/2"	18	Oval head counter sunk	Can Use 4805B - possibly 1 9/16" long - steel	4
3513BD	1923 - 1927	Bolt for mounting steering column to the firewall	5/16"	1 1/2"	18	Oval head counter sunk	Can Use 4805B - possibly 1 9/16" long - steel	4
3514		Nut	5/16"		18	Hex	Brass or steel - 1/4" x1/2"?	4
3516C	1912 - 1921	Steering Column Shaft	1/2"		20		Drilled - 4:1 gear ratio - what else is different	1
3516D	1921 - 1925	Steering Column Shaft	1/2"		20		Drilled - 4:1 gear ratio	1
3516E	1926 - 1927	Steering Column Shaft	1/2"		20		Drilled - 5:1 gear ratio	1
3518	1909 - 1927	Steering Gear Pinion	5/8"		11 or 18		short pins - 2 used in later years?	3
3518B	1921 - 1927	Steering Gear Pinion	5/8"		11 or 18		long pin, use 2 of short in later year?	1
3520		Steering Wheel Key	3/16"	21/32"			square key 3/16"	1
3523		Steering Post Castle Nut	1/2"		20	Castle	Can use 2551B - holds on steering ball arm	1

3529		Spark and Throttle Rod pin	3/32"	9/16"					2
3537		Bolt - Nut	#8	7/32"	32			what is this and how many? Does it have to do with the steering rod throttle lever, bolt on style see 6927 it appears to have a bolt/nut	?
3540		Steering Bracket Bolt	3/8"	2 1/4"	24	Hex	drilled		1
3541		Steering Bracket Bolt	3/8"	?	24	Hex	drilled		2
2515		Steering Bracket Nut	3/8"		24	Castle			3
3548		Steering Gear Ball Arm Key	?	?			Woodruff		1
Body / Firewall / Dash									
3602D		Body Bracket to Sill Bolt	7/16"	29/32"	20				6
3602E		Body Bracket to Sill Bolt	7/16"	1 1/32"	20				6
3602F		Nut	7/16"		20	Castle	Can Use 2719		6
3639MB	1909 - 1910	Screw to mount firewall to frame brackets	1/4"	1 5/16"	28	oval	Brass. Also used to mount side lamp brackets to the firewall - Macs lists length as 1 1/4" 5/16" - 18?		4?
?	1909 - 1910	Nut	1/4"		28	hex	Brass 5/16" - 18?		4?
3645	1911 - 1916	Bolts to mount firewall to brackets	5/16"	1 5/16"	18	Carriage?	Used with 3640-41 brackets		4
?	1911 - 1916	Nut	5/16"		18	hex	size is questionable.		4
3652	1911 - 1916	Bolt for mounting firewall to bracket	5/16"	3/4"?	18	Carriage	Used with butterfly bracket		4
?	1911 - 1916	Nut	5/16"		18	Square	Can use 4805C		4
3634DBMB	1909 - 1911	Dash bracket mounting screw and nut				round head	Brass - for mounting 3634DB		13 pieces
3635MBR	1909 - 1914	Dash bracket mounting screw and nut set				round head	Brass - for mounting 3634DW or 3635DWBR		8 pieces
3635MS	1912 - 1914	Dash bracket mounting screw and nut set				round head	steel used for mounting 3635DWS		8 pieces
3657MB	1909 - 1911	screw and nut set	1/4"	1 5/16"	28	oval	brass - for mounting sidelight brackets to firewall		?
3657MS	1911 - 1914	screw and nut set	1/4"	1 5/16"	28	oval	steel - for mounting sidelight brackets to firewall		?
3931	1909 - 1916	Nut for mounting oil lamps	3/8"		24	castellated	brass painted black		?
		Dash to Body bracket to frame Bolt	5/16"	7/8"	24	Hex	Drilled		2
		Nut	5/16"		24	Castle	1/2"		2
3666		Bolt	1/4"	1"	20	Hex			2
3667		Nut	1/4"		20	Hex	3/16" x 1/2"		2
Springs									
3809	1909 - 1919	Front Spring Clip Nut	1/2"		20	Castle	Can Use 2568		2

3809B	1919 - 1927	Front Spring Clip Nut	9/16"		18	Castle	1/2' - 20?	2
3811		Front Spring Tie Bolt	5/16"	2 3/16"	24	Square	Head 5/16" Thick and 9/16" square	1
3811C		Front Spring Tie Bolt	5/16"	2 1/2"	24	Square	Head 9/16" square	1
3811N		Front Spring Tie Nut	5/16"		24	Square	9/16" Square	1
3813F	1909 - 1912	Front Shackle, May West type	7/16"		20	Drilled		2
3813BF	1913 - 1916	Front Shackle, Figure 8 type	7/16"		20	Drilled		2
3813B	1917 - 1922	Front Shackle, L type	7/16"		20	Drilled		2
3813B-OR	1923 - 1927	Front Shackle, U type	7/16"		20	Drilled	can use 3813BRE for non-original	2
3815	1909 - 1927	Front Spring Shackle/Hanger Nut	7/16"		20	Castle	Can Use 2719	4
3818	1909 - 1915	Front Spring Perch - Right	5/8"		18	Drilled	Use as general guide for the year, check parts identification book	1
3818B	1919 - 1927	Front Spring Perch - Right	5/8"		18	Drilled		1
3819	1909 - 1915	Front Spring Perch - Left	5/8"		18	Drilled	Use as general guide for the year, check parts identification book	1
3819B	1919 - 1927	Front Spring Perch - Left	5/8"		18	Drilled		1
3821	1909 - 1919	Front Spring Perch Nut	5/8"		18	Castle	15/16"?	2
3821B	1919 - 1927	Front Spring Perch Nut	5/8"		18	Castle	Tapered bottom 15/16"?	2
3833	1909 - 1927	Rear Spring Clip	7/16"		20		Drilled - U shaped	2
3833	1922 - 1927	Rear Spring Clip	7/16"		20		Drilled - U shaped - for 9 leaf spring	2
3834		Rear Spring Clip Nut	7/16"		20	Castle	Can Use 2548 or 3809B	4
3837	1909 - 1925	Rear Spring Tie Bolt	3/8"	2 15/16"	16	Square		1
3838B	1926 - 1927	Rear Spring Tie Bolt	3/8"	3 1/16"	16	Square		1
3838N	1909 - 1927	Rear Spring Tie Nut	3/8"		16	Square	3/8' x 1/2"?	1
3840R	1909 - 1912	Rear Shackle, May West type	7/16"		20	Drilled		2
3840BR	1913 - 1916	Rear Shackle, Figure 8 type	7/16"		20	Drilled		2
3840B	1917 - 1922	Rear Shackle, L type	7/16"		20	Drilled		2
3840B-OR	1923 - 1927	Rear Shackle, U type	7/16"		20	Drilled	can use 3840BRE for non-original	2
3841B	1909 - 1927	Rear Spring Hanger Nut	7/16"		20	Castle	Can Use 3815	
3843	1909 - 1925	Rear Spring Perch	11/16"		16		Drilled - perch is angled and extended	2
3843B	1926 - 1927	Rear Spring Perch	11/16"		16		Drilled - perch at backing plate	2
3845	1909 - 1927	Rear Spring Perch Nut	11/16"		16	Castle	Low profile	2
3847	1912 - 1915	Front Spring Clamp Bolt	1/4"	?	20	Square?	Clamp w/ bolt and nut	2
3847B	1916 - 1927	Front Spring Clamp Bolt	1/4"	?	20	Square?	Clamp w/ bolt and nut	2
3847R	1909 - 1912	Front Spring Clamp Rivet						
3848	1912 - 1916	Rear Spring Clamp Bolt	1/4"	?	20	Square?	Clamp w/ bolt and nut	2
3848B	1918 - 1927	Rear Spring Clamp Bolt	1/4"	?	20	Square?	Clamp w/ bolt and nut	2
3847R	1909 - 1912	Rear Spring Clamp Rivet						

3851		Clip	9/16"		18		Drilled	2
3852		Bolt	3/8"	3 9/32"	24			

3852B	Nut	3/8"	24
-------	-----	------	----

Starting Crank

3902	1909 - 1922	Starting Handle Bolt	1/2"	4 5/8"	20	Oval?		1
3905		Starting Crank Ratchet Pin	5/16"	1 5/8"		Button	1 7/16"?	1
3905SN		Snap on Crank Pin	5/16"				Accessory	1

Radiator

3926		Radiator cap	?				Whole variety of these will not be specified here.	1
3929	1909 - 1916	Radiator Mounting Stud	3/8"	2 7/16"	24	None	Drilled one end, threaded both ends	2
3929B	1917 - 1925	Radiator Mounting Stud	3/8"	2 7/8"	24	None	Drilled one end, threaded both ends	2
3929B-2	1926 - 1927	Radiator Mounting Stud	3/8"	3 1/2"	24	None	Drilled one end, threaded both ends	2
3929C		Radiator Stud Nut	3/8"		24	Castle		2
3929P		Radiator Stud Plate Nut	3/8"		24	Rectangular	located in frame	2
3931	1909 - 1916	Radiator Stud Nut	3/8"		24	Castle	Brass	
3932	1909 - 1922	Radiator Support Rod	3/8"	20 3/4"	24		for cars with wood firewalls, from dash to radiator	1
3932A	1911	Radiator Support Rod	3/8"		24		torpedo Roadster	1
3932C	1923 - 1925	Radiator Support Rod	3/8"	20 3/4"	24		metal firewall	1
3932D	1926 - 1927	Radiator Support Rod	3/8"	19 1/2"	24		metal firewall	1
3934		Radiator Support Rod Nut	3/8"		24	Hex	can use 3066B	2?
3945 Bolt		Radiator Hose Clamp Bolt	#10	1"	24	Round / Slotted	or 3/16" x 1" Stove bolt & nut	6
3945 Nut		Radiator Hose Clamp Nut	#10		24		7/16"	6
3947	1916 - 1927	Radiator Shell mounting Bolt				flat / slotted square		2
3947N	1916 - 1927	Radiator Shell mounting Nut						2
	1926 - 1927	Radiator Apron Screw						1

Fan

3961B	1909 - 1920	Fan Blade Rivet	5/32"	3/8"		Round	steel	16
3966	1909 - 1920	Fan Shaft	7/16"	4 1/4"	20	special	Drilled	1
3966B	1921 - 1925	Fan Shaft	7/16"	3 3/4"	20	special	Drilled	1
3966C	1926 - 1927	Fan Shaft	7/16"	4 3/8"	20	special	Drilled	1
3986		Fan Shaft Nut	7/16"		20	Castle	Use 2719	1
3968	1909 - 1925	Fan Bracket Bolt	1/2"	2 3/8"	20	?	for belt tension pulley	1
3973	1909 - 1920	Fan Adjusting Bolt	3/8"	1 13/16"	24	Hex		1
3973B	1909 - 1920	Fan Adjusting Nut	3/8"		24	Hex	Can Use 3066B	1
3980	1921 - 1927	Fan Pulley Plug	?			no head, slotted	Grease plug - Brass	1

Exhaust / Muffler	3984		Fan Blade Screw	1/4"	1/2"?	20	Round	Attach fan blades to hub	4
	3985		Fan Blade Lock Washer	1/4"			locking	Use 3261C	4
	3060B		Exhaust manifold	1 7/8"		18			1
	3061		Exhaust Pipe Packing Nut	1 7/8"		18	Hex	Special / Brass	1
	3066		Exhaust manifold clamp stud	3/8"	3 1/4"	16 / 24	No head	Threaded both ends - 16 threads into block	4
	3066B		Exhaust manifold clamp nut	3/8"		24	Hex	9/16"	4
	3066C2		Exhaust manifold clamp stud	3/8"	?	24		Nickel head?	4
	4025CIB	1917 - 1921	Muffler to Frame Mounting Bolt				Hex	drilled - for cast iron muffler	2
	4025STB	1921 - 1927	Muffler to Frame Mounting Bolt				Hex	drilled - for steel muffler	1
	4025CIB		Muffler to Frame Mounting Nut				Castle		1 or 2
	4026CL		Muffler Clamp						1
	4030	1909 - 1917	Muffler Bolt rods	5/16"	13 5/8"	18	none	Mac number, threaded both ends	3
	4030B	1918 - 1921	Muffler Bolt rod	5/16"	14"	18	none	threaded both ends	1
	4031		Nut	5/16"		18	hex	Use 3446 or 2503F	2 to 6
	4033		Bolt & Nut	5/16"	1 13/8"	18	Hex	Use 1-4819B & 1-4819D or 3514	1
	4035		Washer	1/4"					
	4041		Bolt & Nut					Use 1-2722 & 1-3066B	2
	4041B		Bolt & nut					Use 1-3074 & 1-3074B or 2515	
	4061C		Screw	?	?		?		
Carburetor	4130	1909 - 1927	Carburetor to Manifold Bolt	?			Hex		2
	4130B	1909 - 1927	Carburetor to Manifold Nut	?			Hex		2
	4130GEN	1919 - 1927	Carburetor to Manifold Standout Bolt	?			Hex	Cabruretor accessory stand-out bolt. Extra long special bolt that makes getting a wrench to the carburetor easier when installing it or removing it. This is for a car with a generator. Not for use with vaporizer carburetors	2
	4130NOGEN	1909 - 1918	Carburetor to Manifold Standout Bolt	?			Hex	Carburetor accessory stand-out bolt. Extra long special bolt that makes getting a wrench to the carburetor easier when installing it or removing it. This is for a car without a generator.	2
	There are a bunch of carburetor threaded components, some listed below. This area should be expanded and separated by general, and specific carburetor types.								
	6208		Nut					blue color just not looked at yet	
	6208B		Nut						
	6210		Pin						
	6211		Screw						
	6212		Seat						

6213		Needle Assy	?						
6213B		Needle Assy	?						
6214B		Spray nozzle	?						
6215		Plug	?						
6216		Drain plug	?						
6217		Screw	?						
6220		Inlet needle	?						
6221		Valve body	?						
6151		Valve body	?					Brass	
6154	1913 - 1926	Carburetor Inlet Elbow	?					Brass	1
6161		Needle Assy	?						
6161B		Needle Assy	?						
6162		Nut	?						
6163		Nut	?						
6163B		Nut	?						
6165		Sleeve	?						
6165B		Nut	?						
6166		Pin	?						
6169		DrainPlug	?						
6170		Screw	?						
6171		Stop Assy	?						
6172		Seat	?						
6173		Shaft Assy	?						
6210/12		Float valve	3/8"		16			3/8-16 or 7/16-24	
6245		Data plate rivet	1/16"	3/16"					
6255		Screw	?						
6263		Shaft Assy	?						
6264		Screw	?						
6265		Screw	3/64"	19/64"					
6266		Lock washer	5/32"						
6267		Screw	?						
6271		Nut	?	3/4"		Round head			
6275		Screw	5/16"		18				
6278		Nut	?						
6283		Seat	?						
6286		Nozzle	?						
6291		Valve body	?					Brass	
6295		Elbow	1/8"		NPT			to the carburetor	
6297B		Bolt	?						
6297C		Nut	?						
6304		Set screw	?						

**Coils and Coil
Boxes**

4665-X	Rivet	5/32"	5/16"		Special	blue color just not looked at yet	
4805B	Bolt	5/16"	3/4"	18	Carriage		6
4805C	Nut	5/16"		18	Square	1/4" x 9/16"	6
4806B	Eye bolt	3/8"		16			4
4806C	Washer	3/8"					4

4806D	Nut	3/8"	11/16"	16	Hex	Use 2825B	4
4808	Bolt	3/8"	29/32"	16	Hex		2
4808B	Bolt	3/8"	1 1/32"	16	Hex	Use 3362	2
4808C	bolt	1/4"	5/8"	20	Hex		4
4808D	Nut	3/8"		16	Hex	Use 2515	4
4808E	Nut	1/4"		20	Hex?	Use 3088E	4
4817B	Nut	7/16"		20	Hex	3/8" x 11/16"?	4
4819	Bolt	1/4"	1 1/4"	20	Carriage		4
4819B	Bolt	5/16"	1 3/8"	18	Carriage?		4
4819C	Nut	1/4"		20	Hex?	Castle?	4
4819D	Nut	5/16"		18	Hex?	Castle?	8
4820	Bolt & nut					Use 1-4808C & 1-4808E or 3088E	
4820C	Bolt	5/16"	3/4"	18	Carriage		4
4864	Lock washer	5/16"					
4865	Bolt	1/4"	5/8"	20	Hex		
4866	Nut	1/4"			Square	3/16" x 1/2"?	
4867	Washer	1/4"					
4868	Lock washer	1/4"					
4872	Lock washer	5/16"				3/32" x 23/32"	
4873	Bolt	5/16"	?				
4880	Screw	#12	1"		Flat Head wood screw	Steel bright	
4881	Washer	#12				or 1/4"	
5000B	Bolt	1/4"	?	20	Carriage	Special head /cut off on one side Coil box mounting bolt	4
5000BN	Nut	1/4"		20	Hex		4
5005B	Bolt	#10	?	32?	Carriage	Coil box terminal bolts	10
5005BN	Nut	#10		32	Hex	Brass	20
5007N	Nut	#12		?		For coil points	

Starter

5019	1919 - 1927	Starter Drive head	5/16"		24			1
5020	1919 - 1927	Starter Drive Woodruff Key	1/8"	1/2"				2
5021		Shaft	5/16"		24			1
5023		Starter Bendix shaft spring screw	5/16"	1"	24	Hex	1/2"?	1
5024		Starter Bendix head spring screw	5/16"	1"	24	Hex	Rounded- extended tip - 1/2"?	1
5025		Washer / Locl	5/16"				Special / 2 tabs	2
5045		Screw	#8	1"?		Round	Wood screw	2
5052		Bolt	5/16"	1"-1 1/2"	18	Square	Lead coated	2
5052B		Nut	5/16"		18	Hex	Special/ shoulder // lead coated 9/16"?	2
5059	1919 - 1927	Bendex Cover Screw	#14	3/4"	24	Pan head	size is questionable	4
5060		Screw	#10?	?		Round		5
5061		Screw	?	?		?		3

5062		Starter Motor Mounting Screw	3/8"	1/2"	16	Round	Often changed to a hex bolt to make it easier to mount	4
5062B?		Lock Washer	3/8"				For 5062 Screw	4
5101B		Starter (or Generator) Band Screw	#10	1"	24	Round	or 3/16" for 5101 band	2
5101C		Starter (or Generator) Band Nut	#10	3/8"?	24	Square	or 3/16" for 5101 band	2
5103B		Screw	#10	5/8"	32	Pan Head	For 5103 to 5118 & 5130 to 5145	12
5103C		Lock Washer	#10				For 5103B and others	20
5107TS	1919 - 1927	Starter Terminal Stud	3/8"		16		used to attach battery cable	1
5108		Starter Brush holder assembly	#10		32		tapped holes in brush holders are 10/32	1
5108R		Starter Brush holder assembly Rivet	3/32"	1/4"		Oval	Attaches brush holder to end cap - copper	4
5112		Starter Terminal Nut	3/8"		16	Hex	Brass / Jam 5/8" wrench	2
5113		Generator/Starter Field Coil Screw	3/8"	1/2" or 5/8"	16	Flat / countersunk, straight slot	Same number / type for starter. Pole shoe screw	8
5118		Starter yoke / field housing	#10		32		holes with tapped threads are 10/32	1
Generator								
5058		Generator Mounting Bolt	3/8"	2 15/16"	24	Hex	5/8" Head / 3/16" Thick	2
5020		Generator gear small key					See Starter group	
5101B		Starter (or Generator) Band Screw					See Starter group	
5101C		Starter (or Generator) Band Nut					See Starter group	
5113		Generator/Starter Field Coil Screw					See Starter group	
5114		Screw	#10	5/16" -3/8"	32	Round		8
5116		Flat Washer	3/8"				Brass 1/16" x 11/16"	1
5117		Flat Washer	3/8"				Steel 1/16" x 11/16"	1
5123		Generator Terminal Bolt	1/4"	1"?	26	Carriage	Brass	1
5134		Generator Terminal Nut	1/4"		26	Hex	Copper Plated Steel	2
5130		Generator Head	3/8"		24		tapped mounting holes are 3/8-24	
5130S ?		Screw	#10	3/4"	32	Pan Head	Attaching screw for 5130 or 5103	12
5132BS ?		Screw	#6	1/4"	32	Round	For 5132B to 5124	4
5132BW ?		Lock Washer	#6				For 5132BS	4
5134B		Nut	#10		32	Hex	5/16"	1
5135		Generator Oiler	1/4"		28		Nickle Plate?	1

5136		Generator Pinion to Shaft Pin	3/16"	1 1/2"				1
5141		Stud	#10	?	32	Oval		1
5141B		Stud	#10			Oval/truss		1
5142		Washer	1/4"				Fiber	1
5142B		Washer Lock	#10					1
5145		Generator Yoke / Field housing	#10		32		holes with tapped threads are 10/32	1
Battery								
5151		Battery Clamp Bolt	3/8"	1"	16	Carriage		2
5151B		Battery Clamp Nut	3/8"		16	Hex		2
5151W?		Washer / Lock	3/8"					2
5181		Terminal post nut						2
5178		Cell cover						3
5184		Cell cap						3
5188		Battery terminal post						1
5189		Battery terminal post						1
5190		Battery terminal -						1
5191		Battery terminal +						1
		Battery terminal bolt	5/16"	1"	18	Square	Cad plated 1/2"	1
		Battery terminal nut	5/16"		18		Cad plated 9/16"	1
Spark Plugs								
5200 / 5201		Spark plug	1/2"		pipe		Base	4
5200 /5201		Spark Plug	#8				Terminal end	4
14mm-AD		Adapter for spark plug	1/2"		pipe		1/2" pipe to 14 mm	4
Lights								
6511HX		Headlight Assy	1/2"		20		Mounting post	2
6511KX		Headlight Assy	1/2"		20	Castle	Mounting post	2
6504?	1926 - 1927	Headlight mounting bolt				carriage	Mounts headlights to headlight bar	2
6504?	1926 - 1927	Headlight mounting Nut				hex		2
6504?	1926 - 1927	Headlight mounting washer					conical washer	2
29X		Nut	1/2"		20	Hex	Use 2825B	2
339X		Nut	?			Oval	Use 4817B	2
6580X		Screw	?					2
6592X	Wire attaching screws	Plug	#5		36	?		
6393X		Bolt / nut	?					2
7810X		Bolt	?	?		Oval		
8028X	Screw and nut	Screw /nut	?	?		?		1
1154X		Bolt / nut	?	?		?		?
2449BX		Screw	?	?		?		?
2257BX		Screw	?	?				?
8891X		Cotter pin	?	3/4"		Carriage		?
		Running board mounting bolt	5/16"	1/2"?	18	Hex		4

	"	"	Nut	5/16"	18		4
	"	"	Lock Washer	5/16"			4
421X			Cotter pin	3/32"	1"	Fac # 421 / A23533	
753X			Cotter pin	3/32"	3/4"	Fac # 753 / A23531	
82X			Cotter pin	1/8"	1"	Fac # 82 / A23550	
66X			Cotter pin	3/32"	1/2"	Fac # 66/ A23530	
544X			Cotter pin	1/16"	1/2"	Fac # 544/ A23515	
88X			Cotter pin	3/32"	5/8"	Fac #88 / A23534	
1164X			Cotter pin	3/32"	5/8"	A23532	
1094			Cotter pin	1/8"	1 1/4"	A23552	
TT1014			Cotter pin	5/32"	1 1/2"	A23566-R	
TT2461X			Cotter pin	3/32"	1"	A23565	
TT-8309-X			Rivet	5/16"	5/8"	Special head	
			Rivet	1/4"	7/8"	Round	
			Rivet			Brake quadrant	
			Lock washer	#10		Frame	
			Lock washer	#12			
			Lock washer	1/4"			
			Lock washer	5/16"			
			Lock washer	3/8"			
			Lock washer	7/16"		2584D	
			Lock washer	1/2"			
			Lock washer	9/16"		2550	
			Flat washer			Front bumper arm bracket to frame	
A20915			Bolt			use 3602E	
2431X			Bolt			Bumper rail end clamp	
3111SX			Bolt			Rear bumper arm spacer, (Roadster)	
3140SX			Bolt			Rear bumper arm spacer, (Coupe)	
3136SX			Bolt			Rear bumper arm spacer, (Tudor, T.C.)	
3143SX			Bolt			Rear bumper arm spacer, (Fordor)	
3141SX			Bolt				
926X			Nut			Bumper rail center clamp bolt / use 3514	
78X						Bumper rail end clamp bolt / use 2549	

Ruckstell Parts	RUCKSTELL	1913 - 1927					
	PARTS // TRUCK						
	P-11		Shift lever knob	?			1
	P-11A		Shift lever knob	?	authentic, no script		1
	P43		Differential casing bolt				6
	P43?		Differential casing nut				6
	2564		Clevis pin for shift rod				2
	P-89		Pinion gear (idler) pin set				3

P-128		Ring Gear Bolt	?				10
P-148A	1913 - 1925	Shifter housing				threaded adjustment hole	1
P-148C	1926 - 1927	Shifter housing				threaded adjustment hole	1
P-151A		Housing Plug	1 1/8"			for P-148A	1
P-151C		Housing Plug	1 1/4"			for P-148C	1
P-151D		Housing Plug	1/2"	no		for P-148C	1
P-158CP		Spring tension adjustment plug			flat - slotted	for P-148C	1
P-158S1	1913 - 1925	Mounting Bolt				For P147 with brass body	2
P-158S2	1913 - 1925	Mounting Bolt				For P147 with brass body	1
P-158S3	1913 - 1925	Mounting Bolt				For P147 with brass body	1
P-158AS1	1913 - 1925	Mounting Bolt				For P158A / P147 with cast iron body	2
P-158AS2	1913 - 1925	Mounting Bolt				For P158A / P147 with cast iron body	1
P-158AS3	1913 - 1925	Mounting Bolt				For P158A / P147 with cast iron body	1
P-158BS1	1926 - 1927	Mounting Bolt				For P158C / P147 with cast iron body	2
P-158BS2	1926 - 1927	Mounting Bolt				For P158C / P147 with cast iron body	1
P-158BS3	1926 - 1927	Mounting Bolt				For P158C / P147 with cast iron body	1

TT Parts - Not looked at

1001	right	axle housing	3/4"		Pipe	1) 3/4" USS pipe thread // drain hole; 2) 3/8" x 24 flange hole?	1
1002	left	axle housing	3/8"		24	Flange holes	1
1003	axle housing	Bolt	3/8"	9/16"	24 Hex	Drilled	13
1003B	Use 2719	Nut	3/8"		24 Hex	Castle	13
1004	axle housing	cap	3/4"	1 1/16"	Pipe	3/4" USS pipe thread// plug hole	1
1006	axle housing	Bolt	1/2"	1 1/8"	13 Hex	Drilled head	4
1012	axle housing	Plug	3/4"	1 1/16"	Pipe Square		2
1013	shaft	Axle	7/8"		14		2
1014	axle shaft	Cotter pin	5/32"	1 1/2"			2
1015	axle shaft	Nut	7/8"		14 Castle	29/32" x 1 1/4"	3
1016	axle shaft	Washer	7/8"			1/8' x 1 3/4"	2
1023	axle shaft bearing retainer	Washer	1 3/4"			1/16' x 31/32"	
1029	Use 1003	Bolt.	?	?	Hex	?	8
1030	Use 2719	Nut					
1034		Drive shaft	1/4"			1/4" holes for pins?	1
1038	Use 1006	Bolt					4
1042	Drive shaft to worm	Pin	?	?			2
1043 & B	Threaded shaft of worm	Worm	7/8"		14		
1045	Use 1014	Cotter pin	?	?			1
1049	worm roller bearing	Screw	?	?	?		2
1054	Use 1015	Nut	7/8"		14 Castle		1

1055	worm thrust bearing retainer	Pin	7/32"	1/2"			7/32" / 1/4"	1
1058	lining	Rivet	3/16"	9/16"		Oval	Brass / Split	40
1060	brake shoe	Bolt	5/8"	?	18	Hex		2
1060B	Use 2507 / brake shoe	Nut	5/8"		18	Hex	Castle	2
1061	brake shoe	Expander	?				Drilled	2
1066	brake expander	Clevis pin	3/8"	1"		Oval	Drilled	2
1068	brake expander link	Clevis pin	?	?		Flat	Drilled	8
1072	brake rod support	Bolt	1/4"	1 9/16"	20	Carriage	Head Diameter = 1/2"	2
1072B	Use 3088E / brake rod support	Nut	1/4"		20	Square		2
1074	rear radius rod (front)	Bolt	5/8"	3 7/8"	18	Hex	Drilled 15/16"	1
1075	Rear radius rod (rear)	Bolt	5/8"	2"	18	Hex	Drilled	4
1075B	Use 2507/rear radius rod bolt	Nut	5/8"		18	Castle		5
1089	spring clip	Nut	5/8"		18	Castle		4
1092	spring tie	Bolt	?	?		Hex	Drilled	2
1093	Use 1089/ spring tie bolt	Nut						
1094	spring tie bolt	Cotter pin	?	?				2
1096	spring clamp	Bolt	5/16"	3 7/8"	18	Hex	Head slightly different than most bolts	2
1096B	Use 3514/spring clamp bolt	Nut	5/16"		18	Hex		2
1098	Use 1015/ spring perch	Nut						2
1099	Use 1014	Cotter pin						
1107B		Clamp & nut	?					12
1108B		Bolt	?	?		Special		12
1108C		Bolt	?	?		Special		12
1108D		Nut	?			Hex	Special	12
1111		Hub / TT	?					2
1114		Bolt	1/2"	?	20	Carriage		12
1114B		Nut	1/2"		20	Hex	Large	12
1116		Hubcap / Truck rear	?					2
1117		Key	?	?		Square		2
1161		Bolt	3/8"	?	24	Square	Thick head	1
1162	Use 3811B	Nut	5/16"		24	Square		1
1164B		Spring clip	5/8"		18		Drilled shaft	1
1166	Use 2507	Nut	5/8"		18	Castle		2
	Frame rivets	Rivets	1/4"	7/8"		Round		?